



# iMac Intel 24" EMC 2267 RAM Replacement

Use this guide to replace or upgrade your RAM chips.

Written By: johann beda



## INTRODUCTION

Use this guide to replace or upgrade your RAM chips.



### TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [Spudger](#) (1)



### PARTS:

- [PC3-8500 1 GB RAM Chip](#) (1)
- [PC3-8500 2 GB RAM Chip](#) (1)
- [PC3-8500 4 GB RAM Chip](#) (1)

## Step 1 — Note - most of this guide was taken from the info for: iMac Intel 20" EMC 2266



- Lay your iMac front side down on a table with the lower edge facing yourself.
- Loosen the single Phillips screw PH#2 in the center of the access door.
- ⓘ This screw is captive in the access door.
- Remove the access door from your iMac.

## Step 2 — Note - most of this guide was taken from the info for: iMac Intel 20" EMC 2266



- Use the sharp end of a spudger to pull the black plastic RAM tabs out of the memory bay.  
Formatting help
- Pull the black plastic RAM tab away from your iMac to eject the RAM chip.





- Grab the RAM chip by its edges and pull it straight out of its slot.
- If two RAM chips are installed, repeat this process for the other chip.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-11-20 12:09:08 AM.